

Get closer to what inspires you.

Unbelievable Kodak quality

- Get close to your subjects with 5X Kodak Retinar all-glass optical zoom
- 4X advanced digital zoom (20X total zoom)
- Create unbelievable-quality prints up to 20" x 30" with its 4.0 MP
- Get rich, vibrant color under a variety of lighting conditions with the exclusive Kodak color science chip
- Capture consistently crisp, precise pictures thanks to the multi-zone auto-focus with low-light performance

Creative performance controls

- Easily access its 17 programmed scene and 3 color modes
- Get the best shot time after time with its continuous shooting mode
- Capture life in motion with continuous VGA (640 x 480) video
- Be in control with advanced manual and custom controls, including selectable aperture priority and shutter priority

Sharing made simple

- Print, e-mail, and organize your photos with just one touch of our exclusive Share button
- View your pictures on the 1.6" indoor/outdoor display
- Snap a picture in almost any mode with Capture Always Ready
- Works with optional Kodak EasyShare printer dock series 3 and Kodak EasyShare camera dock series 3†



Your needs are simple: pictures that are nothing short of exceptional. And, not to mention, you want to get those pictures with ease. Well, here's your camera: the Kodak EasyShare Z700 zoom digital camera. It's packed with everything you need to capture outstanding pictures, including one very important feature: point-and-shoot ease. So whether you're zooming in close with its powerful 5X optical zoom, want to print up to 20" x 30" with its 4.0 MP, or are looking to capture the perfect shot using its artist-inspired creative settings, you can do it simply. So go ahead – be demanding. The Z700 will deliver.

Just press 

Z700

High Zoom Series



Making digital even simpler

The optional Kodak EasyShare printer dock series 3 is the simplest way to go from picture to print. Just dock your Z700, touch the button, and get real Kodak borderless pictures up to 4" x 6". It even works with or without a computer, and features an auto enhance button for great-looking prints time after time. And just like the optional Kodak EasyShare camera dock series 3, the printer dock series 3 transfers pictures from camera to computer at the touch of a button and recharges your Kodak camera battery in less than 3.5 hours*.



Standard features

CCD resolution – 4.23 megapixels (2408x1758 pixels)
 Image resolution – 4.0 megapixels (2304x1728 pixels)
 Picture quality
 4.0 MP – best (prints up to 20" x 30")
 3.5 MP – best 3:2 (optimized ratio for 4" x 6" prints)
 3.1 MP – better (prints up to 11" x 14")
 2.1 MP –
 1.1 MP – good (small prints)
 Still format JPEG/EXIF v 2.21
 Lens – 5.8 -29.2 mm (35-175 mm, 35 mm equivalent)
 Advanced digital zoom – 4X
 Aperture – f/2.9-5.8 (wide), f/4.9-8.8 (tele)
 Shutter speed – automatic: 8-1/1600 sec.
 Real image optical viewfinder
 LCD – 1.6" (4 cm) hybrid (transmissive/reflective) TFD,
 72K pixels (312x230) indoor/outdoor display

Performance features

Still capture modes – auto, SCN, sport, landscape, close-up, PAS
 Scene modes – children, party, beach, flower, fireworks, snow, backlight, close-up, night portrait, landscape, night landscape, manner/museum, text/document, self-portrait, sport
 Color modes – color, sepia, black and white
 Click to capture – 0.4 sec. (prev. on), 0.7 sec. (prev. off)
 Shot to shot – 1.2 sec.
 Video mode – continuous MPEG-4 compressed video with audio recording during video capture
 Video resolution – VGA (640x480 pixels) at 13 fps; QVGA (320x240 pixels) at 20 fps
 Video length – continuous up to 80 min. based on memory capacity
 Video format – Quicktime MOV (MPEG-4 compression)
 Auto focus – TTL-AF, continuous AF, single AF
 Auto focus selection – multi-zone, center spot
 Focus range:
 Standard – 0.6 m (2 ft) to infinity
 Macro, wide – 0.05 m – still 0.1 m (2-4 in.)
 Macro, tele – 0.25 m-0.7 m (10-28 in.)
 Landscape – 10 m (33 ft) - infinity
 Sensitivity – ISO equivalent 80-160 (automatic) and 80,100, 200, 400 (manual)
 White balance – auto, daylight, tungsten, fluorescent
 Exposure metering – TTL-AE; selectable: multi-pattern, center-weighted, center spot
 Exposure control – programmed AE
 Exposure compensation – +/-2.0 EV in 0.5 EV step increments
 First and last burst mode – 3 fps, maximum 6 images in any quality mode

Ease of use features

Built-in flash – auto, red-eye, fill, off
 Flash range
 wide – 0.6-3.8 m (2-12.5 ft)
 tele – 0.6-2.2 m (2-7 ft)
 Review options – 1X–8X magnify with pan, slide show, multi-up, fast scroll, protect, album, share/print, label, image storage, copy
 Favorites – print, print all, e-mail, favorite, cancel prints
 Dedicated buttons – delete, Share, review, menu, flash, LCD on/off/information, burst/self-timer
 Software – Kodak EasyShare software
 Storage – 16 MB internal memory, SD/MMC card expansion slot
 Self-timer – 10 seconds, 2 seconds

Additional features

Dock compatibility – works with Kodak EasyShare printer dock series 3 and Kodak EasyShare camera dock series 3†
 ImageLink print system compatible
 Power options – optional 2005 Kodak EasyShare docks with Ni-MH rechargeable battery pack; 2 AA Kodak Max digital camera batteries; 2 AA lithium or Ni-MH batteries or 1 CRV3 lithium battery; 3 volt DC
 Lens protection – built-in lens barrier
 Tripod mount – 1/4 in. standard
 I/O interface – power input (3V DC), A/V output (NTSC or PAL, user selectable), exclusive Kodak camera dock/printer dock interface, digital (USB 2.0) connector
 Weight – without batteries: 219 g (7.7 oz)
 Dimensions – WxHxD: 96.8x72.4x55.6 mm (3.8x2.85x2.2 in.)
 Warranty – one year

Minimum system requirements

Windows 98, 98SE, ME, 2000 SP1, or XP OS
 233 MHz processor or greater (300 MHz recommended for XP)
 64 MB RAM (128 MB for XP)
 Internet Explorer 5.01 or higher
 PowerMac or PowerBook G3, G4, G5; iMac; eMac; or iBook
 Macintosh OS X 10.2.3-10.2.8, 10.3 or greater
 128 MB RAM for OS X (64 MB RAM for OS 8.6/9.x)

Minimum hardware requirements

200 MB hard drive disk space available
 CD-ROM drive
 Available USB port
 Color monitor; 800x600 display resolution, 16-bit minimum

Package contents

Kodak EasyShare Z700 zoom digital camera
 Kodak Max digital camera batteries AA or equiv.
 USB cable and audio/video cables
 D-22 adapter plate kit (for a limited time only)
 Wrist strap
 Kodak EasyShare software
 Getting Started kit
 Custom camera insert for optional Kodak EasyShare camera and printer docks

Ordering information

Kodak EasyShare Z700 zoom digital camera
 000 0000 – U.S. and Canada

Recommended accessories

| | |
|---|----------|
| 1. Kodak EasyShare printer dock series 3 | 000 0000 |
| 2. Kodak color cartridge and photo paper kit | 123 1349 |
| 3. Kodak EasyShare camera dock series 3 | 000 0000 |
| 4. Kodak 8-in-1 card reader | 142 7939 |
| 5. Kodak SD memory cards | |
| 128 MB | 124 7667 |
| 256 MB | 810 0919 |
| 512 MB | 833 1613 |
| Kodak EasyShare Ni-MH rechargeable battery pack | |
| 114 8683 | |
| Kodak EasyShare Ni-MH rapid battery charger | |
| 806 5997 | |
| Kodak EasyShare picture viewer | 000 0000 |
| 6. Kodak EasyShare travel kit | 131 8047 |
| 7. Kodak digital camera tripod | 806 2135 |
| 8. Kodak EasyShare camera bag | 000 0000 |



†Compatibility identified by this mark. (Kodak dock adapter D-22 included to ensure compatibility with Kodak EasyShare printer dock plus, printer dock, printer dock 6000 and camera dock 6000).

*Actual battery charging time may vary by camera model.

For more information on the Kodak EasyShare Z700 zoom digital camera, visit www.kodak.com/go/easyshare



©Eastman Kodak Company, 2005. Kodak, EasyShare, Max, the Share button, Retinar, ImageLink and the ImageLink print system logo are trademarks of Eastman Kodak Company. Product specifications subject to change without prior notice. Simulated screen images.
 IC-0000 CAT No. 000 0000

