











Quick Start Guide for the KODAK Photo Printer 6800/6805

Quick Setup
Installation rapide
Kurzübersicht
Instalación rápida
 快速安装
 クイックセットアップ
 빠른 설치



EASTMAN KODAK COMPANY
 Rochester, NY 14650
 ©Eastman Kodak Company, 2002
 P/N Printed in U.S.A.

KODAK Photo Printer 6800/6805
 Imprimante photo 6800/6805 KODAK
 KODAK Fotodrucker 6800/6805

KODAK Photo Printer 6800/6805
 KODAK 6800/6805 照片打印机
 KODAK フォトプリンター 6800/6805

KODAK Photo Printer 6800/6805

PN3J2079

* Items sold separately. * Artículos vendidos por separado. * 기타 품목은 따로 구매합니다.
 * Articles vendus séparément. * 组件另行销售.
 * Separat erhältliche Komponente. * 別売

■ - Black ■ - Green PMS 570C ■ - Red PMS 485C ■ - KODAK Yellow