KODAK EasyShare DX3900 Zoom Digital Camera





- 3.1MP resolution
- 6X zoom (2X optical and 3X digital)
- Automatic and manual settings
- Removable CompactFlash memory card
- Compatible with the KODAK EasyShare Camera Dock

The high-performance camera.

Picture-perfect

Being behind the camera is second nature. You love the creativity, the chance to capture the shot you'll be proud to print and share. The EasyShare DX3900 is for you. Thanks to 3.1MP resolution, you'll get excellent picture quality for prints up to 11" x 14". Its 6X zoom (2X optical and 3X digital) lets you get closer to your subject for crisp detail.

Be in creative control

For the ultimate in creative freedom, set your own color mode, ISO, and lighting exposure settings to get your perfect picture. The DX3900 comes with a CompactFlash memory card to keep you shooting longer. And with the DX3900's optional telephoto, wide-angle, and close-up lens attachments, you can extend your creativity.

Share with ease

If you use the optional KODAK EasyShare Camera Dock, sharing is just as easy. Simply place your DX3900 in the dock, touch the button, and pictures are automatically sent to your computer ready for e-mailing and printing. The Camera Dock will also recharge your camera's battery pack, so you'll always be ready to take more pictures.

The EasyShare System









KODAK EasyShare DX3900 Zoom Digital Camera



Auto flash

Close-up, lighting, and exposure settings

> Compatible with optional lens attachments

Built-in lens cover

3.3 megapixel

3.1 megapixel,

(2160x1440 pixels)

3.1MP (default setting)

up to 28 x 36 cm (11 x 14 in.)

3.1MP (high compression) up to 20 x 25 cm (8 x 10 in.)

2.2MP up to 20 x 25 cm

(8 x 10 in.), 1.6MP up to

15 x 20 cm (5 x 7 in.), 0.8MP e-mail

maximum 8 pictures at

(35 mm equiv.), auto focus

6X (2X optical, 3X digital)

standard: 0.50 m - infinity,

macro-wide: 0.07m - 0.7m

macro-tele: 0.25m - 0.7m

weighted, center spot)

16 sec to 1/2000 sec

automatic, fill, red-eye, off

100, 200, 400 (selectable)

automatic, daylight, tungsten,

black and white, sepia, color

real-image optical viewfinder

38 mm (1.5 in.) review/

KODAK Picture Software

preview color display

100 - 400 (automatic)

wide: 0.5m - 3.2m

tele: 0.5m - 2.3m

(1.6 - 10.5 ft.)

(1.6 - 7.5 ft.)

fluorescent

10 seconds

JPFG

TTL-AE (multi-pattern, center

0.8MP resolution

35 mm - 70 mm

(1.6 ft. - infinity)

(0.2 - 2.3 ft.)

(0.8 - 2.3 ft.)





Includes removable CompactFlash memory card

Color LCD display to preview and review your pictures

Burst mode

Color, Black and White. and Sepia settings

Great Picture Quality

CCD resolution image resolution

image quality

modes

burst

lens

700m focus distance

exposure control

shutter speed flash range

flash mode

ISO equivalent

white balance

color mode self-timer file format

Easy to Use

viewfinder LCD

software

Take More Pictures

storage

Removable CompactFlash memory card

Share Pictures Faster

digital still print marking

DPOF printing

interface USB, KODAK EasyShare

Camera Dock compatible NTSC, PAL (user-selectable) video out

Other Specifications

certification FCC Class B, ICES-003 Class B, CE, VCCI, C-tick

tripod mount standard

power options optional Camera Dock with Ni-MH rechargeable battery

pack (in-camera charging); 2AA Ni-MH rechargeables: 2AA Lithium batteries or 1 CRV3 Lithium battery

without batteries: weight 225 g (7.9 oz.)

WxHxD: 116x67x42 mm dimensions

(4.6x2.6x1.7 in.)

warranty one year

System Requirements

WINDOWS:

WINDOWS 98, 98SE, 2000, or ME

Personal computer with 200 MHz processor

48MB minimum RAM (WINDOWS 98, 98SE, ME) 64MB minimum RAM (WINDOWS 2000)

100MB hard drive disk space available

CD-ROM drive

Available USB port

Color monitor, 800x600 pixels (16-bit or 24-bit recommended)

MACINTOSH:

PowerPC-based MACINTOSH computer

MACINTOSH OS 8.6/9.x/X

64MB RAM available

100MB hard drive disk space available

CD-ROM drive Built-in USB port

Color monitor, 800x600 pixels

(thousands or millions of colors recommended)

Package Contents

- KODAK EasyShare DX3900 Zoom Digital Camera with wrist strap
- KODAK Picture Software CD
- Cables for USB and video
- Removable CompactFlash memory card
- KODAK CRV3 MAX Lithium battery or equivalent
- Insert for optional KODAK EasyShare Camera Dock
- Documentation kit

Ordering Information	CAT No.
KODAK EasyShare DX3900	
Zoom Digital Camera (US)	114 7164

KODAK EasyShare DX3900

Zoom Digital Camera (Canada)128 5535

Recommended Accessories

KODAK EasyShare Camera Dock and Ni-MH Rechargeable Battery Pack (US)153 8230 KODAK Lens Adapter (32-37 mm)125 0844 Close-up Lens Kit (37 mm threads)

(Lens adapter required)138 2175 Wide-Angle Lens (0.5X-37 mm threads)

Telephoto Lens (2.0X-37 mm threads) ...179 2860 (Lens adapter required)

KODAK Picture Cards

32MB180 6900

KODAK Picture Launch (USB CompactFlash

KODAK Ni-MH Rechargeable Battery Pack (WW) (for use with Camera Dock)114 8683

KODAK Rapid Battery Pack Recharger .. 891 4012

KODAK MAX Rapid Battery Charger (for use with KODAK Ni-MH Rechargeable

For more information on the KODAK EasyShare DX3900 Zoom Digital Camera, visit www.kodak.com/go/easyshare





