

LS420

Share Moments. Share Life.™



Kodak EasyShare digital camera

The Kodak EasyShare LS420 digital camera. Take pictures of your life. Take it anywhere. It's 2.1MP of pocket-sized power that's just right for the picture-taker on the go. And with a Kodak aspheric, all-glass lens and continuous 3X digital zoom, it will get you close to the action, too. After all, isn't that the best place to be?

Kodak EasyShare system



Shoot. Touch. Share. With the Kodak EasyShare system, sharing is simple. Just place your Kodak EasyShare digital camera into the dock, touch the button, and your pictures are automatically sent to your computer. Now you're ready to e-mail pictures and share great-looking prints with the world.

Simulated LCD display image

Get everything you need

You get it all with the LS420. Its special edition package includes everything you'll need to capture your memories – the LS420 digital camera and its camera dock, a carrying case, rechargeable battery, and neck strap. It also comes with Kodak software that makes it simple to do more with your pictures, including editing, printing, and e-mailing.

Always ready to shoot

The LS420's ready to shoot when you are. It comes with 8MB of internal memory, so you can start shooting right away. You can even boost your camera's memory using its MMC/SD expansion slot.

Transfer with just one touch

With the LS420's special edition camera dock, you can transfer your pictures and videos from camera to computer at the touch of a button. And while the LS420 is docked, its battery pack is also being recharged. So you'll be ready to shoot any time.

Share great-looking pictures

With Kodak color science built into your LS420, you can get rich, brilliant pictures you'll want to e-mail and print. And the One Touch To Better Pictures feature, which comes with the Kodak software, color matches your picture to your inkjet printer when you use Kodak inkjet papers. The result? Prints that come alive.

D I G I T A L M A D E S I M P L E . P R I N T S M A D E B E A U T I F U L .

LS 420



Share Moments. Share Life.™





- 2.1MP for prints up to 8" x 10"
- Aspheric, all-glass lens with continuous 3X digital zoom
- 8MB internal memory and MMC/SD expansion slot
- Captures digital video with sound
- New print-tagging button for use with optional MMC/SD memory card



Great Picture Quality

CCD resolution	2.3MP	
image resolution	2.1MP (1752x1168 pixels)	
image quality	2.1MP (best) 1752x1168, 0.5 MP (good) 876x584	
optical lens	38 mm (35 mm equiv.), f/3.9	
digital zoom	3.0X continuous digital zoom in 0.1X increments	
focus distance	0.8m (29 in.) to infinity	
exposure control	automatic	
shutter speed	automatic (1/2 to 1/1200 seconds)	
flash range	0.8 - 2.5m (2.6 - 8.2 ft.), quenched, charge time 7 sec. max.	
flash mode	automatic, fill, red-eye, night shot, off	
ISO equivalent	100-200 automatic	
white balance	automatic	
file format	JPEG/EXIF 2.2	
user interface controls	power, shutter, menu, joystick with center select, flash/print (for use in review mode)	
movie mode	audio recording during capture, no audio playback on camera	
movie length	unlimited, based on memory size, 5 sec., 15 sec., 30 sec. settings	
movie image resolution	best: 320x240 at 19.1 fps good: 160x120 at 19.1 fps	
microphone	built in	
file format	QuickTime	
viewfinder	real-image optical viewfinder	

LCD	40.6 mm (1.6 in.), transmissive TFD color	
storage	8MB internal memory (approximately 49 images in good quality setting or 12 images in highest resolution setting; approximately 40 sec. of video in highest resolution setting)	
optional storage	expansion slot for optional removable MMC/SD card	
interface	Kodak EasyShare LS420 camera dock	
video out	NTSC, PAL (user-selectable)	
tripod mount	standard	
self timer	10 seconds	
power	Kodak EasyShare lithium-ion rechargeable battery	
camera weight	with battery: 160g (5.6 oz.)	
dimensions	WxHxD: 109x45.5x28.5 mm (4.3x1.8x1.1 in.)	
dock weight	75g (2.7 oz.)	
dimensions	WxHxD: 139.5x35.2x59.1 mm (5.5x1.9x2.3 in.)	

System Requirements

- Windows:
- Windows 98, 98SE, 2000, Millennium Edition, or XP OS
 - Personal computer with 233 MHz processor or greater
 - 64MB RAM available (128MB RAM for Windows XP)
 - 200MB hard drive disk space available
 - CD-ROM drive
 - Available USB port
 - Color monitor, 800x600 pixels (16-bit or 24-bit recommended)

Macintosh:

- Power Mac system
- Macintosh OS 8.6/9.x/X*
- 128MB RAM for OS X (64MB RAM for OS 8.6/9.x)
- 200MB hard drive disk space available
- CD-ROM drive
- Built-in USB port
- Color monitor, 800x600 pixels (thousands or millions of colors recommended)

Package Contents

- Kodak EasyShare LS420 digital camera
- Kodak EasyShare LS420 camera dock
- Kodak EasyShare lithium-ion rechargeable battery
- Camera carrying case
- 5 volt AC adapter
- Video out cable
- USB cable
- Neck strap
- Kodak software CD
- Documentation

Ordering Information

CAT No.

Kodak EasyShare LS420 digital camera (US)896 3472
Kodak EasyShare LS420 digital camera (Canada)815 9493

Recommended Accessories

Kodak MultiMedia Cards (MMC/SD)		
32MB802 4648
64MB853 5692
128MB880 2019
Kodak EasyShare lithium-ion rechargeable battery849 9741
Kodak EasyShare lithium-ion rapid battery charger808 0673
Kodak Multi-card Reader134 2682

For more information on the Kodak EasyShare LS420 digital camera and dock, visit www.kodak.com/go/easyshare

*Free Kodak software upgrade fully enables the print-tagging button for Macintosh OS X. Visit www.kodak.com/go/easyshare for more information.

IC-941 CAT No. 128 2995 ©Eastman Kodak Company, 2002. Kodak, EasyShare, and Share Moments. Share Life. are trademarks.



DIGITAL MADE SIMPLE. PRINTS MADE BEAUTIFUL.